

Bimplus Team eröffnen und verwalten

If you are in *charge* of a project and you want to use the openBIM platform Bimplus to handle this project, you must have your own Bimplus team. Only the team owner (or team administrator) can create new projects and appoint one or more project administrators who manage the projects and who invite more users to join a Bimplus project (see "[Appointing project members](#)").

The users invited to join a project of your team automatically become members of your Bimplus team, thus getting access to Bimplus. Unlike project members, team members can be managed by the team owner (or team administrator) only.

The same is true for Bimplus licenses and Allplan Share licenses that are available to your team. Only the team owner (or team administrator) can distribute licenses to the team members.

Topics in this chapter:

[Opening a Bimplus team](#)

[Managing team members](#)

[Managing team members' rights of use](#)

[Changing the team name](#)

[Back to top](#)